

BROOKS SPA REPAIRS T: 02 9999 3700 M: 0412 463 821 www.brookssparepairs.com.au dean@brookssparepairs.com.au 19 Jendi Ave, Bayview, NSW, 2104

THE SPA REPAIR EXPERTS

BROMINE

Please note that these are general recommendations only

CHEMICALS REQUIRED

Bromine tablets, shock treatment, test kit, Alkalinity increaser, and Filter degreaser

START UP

- Crush 1 bromine tablet and add to spa water
- Place 2 bromine tablets to floating device or skimmer box
- Run spa filter for 1/2 hour and test for bromine and adjust the ph

WEEKLY

- Maintain an average of 1 + 1/2 bromine tablets in skimmer or floating device (More or less if required)
- Add 3 tablespoons of shock (potassium peroxy-monosalphate)(with cover off) and run spa for 1/2 hour.
- Test for bromine and adjust ph and total alklinity with alkalinity increaser

MONTHLY

- Follow weekly treatment
- Remove and clean filter

4 MONTHLY

- Follow weekly treatment
- Remove filter and soak in filter degreaser
- Empty and replace 30% of water

Visit our online shop at shop.brookssparepairs.com.au for all your spa & pool needs





